

Operating Instructions:

To use stimulator independently:

1. Press and hold the button for 3 second to activate; a glowing LED light and a single buzz will indicate the stimulator is activated
2. Press the button to turn on vibrations.
3. Press the button repeatedly until the desired function is reached.
4. To deactivate and turn off, press and hold the button for 3 seconds; the glowing LED light will turn off.

To use with remote:

1. First activate the stimulator by pressing and holding the button for 3 seconds. Activate the remote by pressing the power button once.
2. Using the remote, press the function button to turn on vibrations.
3. Press the function button on the remote repeatedly until the desired function is reached.
4. To turn off the vibrations, press the power button on the remote once.
5. To deactivate, press and hold the button on the stimulator for 3 seconds.

The stimulator must be activated to pair with the remote. To preserve battery life, ensure the stimulator is deactivated after each use. A glowing LED light will indicate the bullet is still activated. Please note: Stimulator will automatically turn off after 30 minutes of inactivity.

Complete Charging Time	Run Time on High	Run Time on Low
75 min	45 min	75 min

LED light will flash while charging and glow solid when fully charged. Fully charge product before use. Battery life depends on frequency and speed of use. We recommend fully charging your product once every 6 months.

Remote Control Toy

CEN No. SE-0582-50-3

A complete declaration of conformity can be obtained at: www.calexotics.com/certificates.aspx

CE 0700

“Hereby, California Exotic Novelties declares that this Remote Control Toy is in compliance with the essential requirements and other relevant provisions of (RED) Directive 2014/53/EU.”

