

VACUUM PUMP PDX ELITE BLOWJOB POWER PUMP



User manual

CONTROL

- 1) Switch on - press the top button to switch on.
There are 2 suction modes. The IST starts in the first mode, which is continuous suction.
- 2) Press the button again to switch to the second mode, intermittent suction.
- 3) Press the top button to alternate between continuous suction and intermittent suction.
- 4) Press and hold the top button for 3 seconds and switch off.
- 5) Quickly release vacuum - press and hold the bottom button "R" to release suction or pulse "R" button for extra stimulation.

MAINTENANCE

After each use, rinse the pump with lukewarm water and soapy detergent.
You can also use an **erotic cleaner**, which also helps to remove microscopic dirt.
Simply spray the product, leave it on for about 1 minute and then dry with a towel or cloth that does not leak fibers.

WATERPROOF

The pump is **not waterproof or water resistant!**

LUBRICATION

Use only **water-based lubricants**. Other lubricating gels could damage the surface of the aid and it could become sticky.

DRIVE AND CHARGING

The pump is powered by two AA batteries. For greater endurance, we recommend using alkaline or rechargeable batteries.

STORAGE

Store separately from other erotic aids in a dry and dark place.

PACKAGING CONTENTS

Vacuum pump and set of penis rings.